



PROJECT NAME : ProRenew Complex CLR

FORMULA NAME : Probiotic Smart Aging Cream

TRIAL CODE : 421.001.09-1

Lab Formula INCI Supplier

Phase	Material Name	Mixed INCI	Supplier	% Material
A	MONTANOV 202	ARACHIDYL GLUCOSIDE ARACHIDYL ALCOHOL BEHENYL ALCOHOL	SEPPIC	5,0
A	TEGO ALKANOL 1618	CETEARYL ALCOHOL	EVONIK	0,5
A	LANOL 99	ISONONYL ISONONANOATE	SEPPIC	8,0
A	MYRITOL 318	CAPRYLIC/CAPRIC TRIGLYCERIDE	BASF	8,0
B	DEIONIZED WATER	WATER	N.A.	70,3
B	EUXYL PE 9010	PHENOXYETHANOL ETHYLHEXYLGLYCERIN	SCHÜLKE	0,8
B	BUTYLENE GLYCOL	BUTYLENE GLYCOL	MERCK	4,0
B	CARBOPOL ULTREZ 10	CARBOMER	LUBRIZOL	0,2
C	PRORENEW COMPLEX CLR	LACTOCOCCUS FERMENT LYSATE	CLR	3,0
D	NAOH (10%)	WATER SODIUM HYDROXIDE	N.A.	0,2
				100,0

Operating instructions

Operating Instructions
Mix A and B separately. Heat up to 80-85°C. Add B to A and homogenize for 2 minutes with Ultra Turrax. Cool down to room temperature under stirring and add C. Adjust pH value 5-5,5 with D. Mix until uniform.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application. They are, to the best of our belief, correct, but are offered without obligation. Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies. This formula has been manufactured and stability-tested using a special preservative, but has not been subjected to microbiological challenge tests.